



The additional speakers from zone 4 are controlled by a separate volume control.

Diagram shown using the NuVo P2100 amplifier

